Installation guide for Encore oxygen sensor OS-J50004.
Torque to 30 ft-lb. Apply anti-seize to the threads only.