VC-D20002 Valve Cover Installation Tip

Part number: VC-D20002

Engine Valve Cover

1. Clean the cylinder head sealing surface before installing the new valve cover.
2. Install the gasket dry. Do not use sealant on the molded gasket.
3. Torque the bolts in sequence to specification, center out.

QA editor test file, New Era internal test. Safe to delete.